


Note : All harness Electric wires are 0.85mm without the directions.

Type : 1 O 1 7 S P

- R : Red
- Br : Black
- Bl : Blue
- W : White
- Gr : Green
- Y : Yellow
- LG : Light Green
- Or : Orange
- P : Pink
- Gr : Gray
- Bw : Brown



1	30A	Chute / Throwing snow motor
2	5A	Auto Chute Control
3	10A	Monitor panel / Fuel meter
4	5A	Start Relay
5	10A	Light / Chute Lever
6	10A	Back auto/Solenoid bulb/Snowmatic
7	5A	Spare
8	10A	Spare

Connection List

Near	1	2	3	4	5
Far	●	●	●	●	●
L	●	●	●	●	●
R	●	●	●	●	●

Engine Switch Connection List

	BAT	IG	ST	B'	E
Stop	●	●	●	●	●
Run	●	●	●	●	●
Start	●	●	●	●	●