

Ersatzteilliste EFCO
Liste des pièces de rechange EFCO

DS 4200 T




Illustration Motor

Bild Nr	St.- Zahl	Teile Nr.	Beschreibung
1	1	2318817R	Kraftstoffpumpe
2	1	61250118R	Mufflerdeckel
3	2	4191069B	Streifen
4	2	3801069R	Schraube
5	2	3819036R	Scheibe
6	2	3916006	Scheibe
7	1	61250194R	Auspuff
8	1	61210035R	Deflector
9	1	3055115	Zündkerze
10	1	61200007AR	Dichtung
11	2	004000015R	Kolbenring
12	2	004900061R	Ring
13	1	50110047R	Kolben ring
14	1	50120034	Kolben komplet Ø40
15	1	61252035	Zylinder kpl.
16	1	50110044R	Lager
17	2	50110043R	Scheibe
18	1	61200001R	Kurbelwelle
19	1	61250250R	Klemmstück
20	1	61200113R	Motorgehäuse
21	4	3860096	Schraube
22	2	094000006R	Lager
23	1	61200006R	Dichtung
24	2	094000099R	Kobelring
25	4	094000101R	Schraube
26	4	3833073	Scheibe
27	2	3023008R	Stift
28	1	3916005R	Scheibe
29	1	3819006	Scheibe
30	1	3801010R	Schraube
31	2	3960030	Schraube
32	3	3960087AR	Schraube
33	1	61250251R	Deckel
34	1	61250046R	Deckel
35	4	3960070AR	Schraube
36	1	61250063AR	Dekompressor
37	1	61202038R	Dichtungssatz
38	1	61250249	Spannhülse
39	1	61252074R	Short block




Illustration Starter und kupplung

Bild Nr	St.-Zahl	Teile Nr.	Beschreibung
1	1	61250205R	Starter komplet
2	1	61200015R	Starter griff
3	1	4098073R	Starterseil
4	8	3819006	Scheibe
5	8	3916005R	Scheibe
6	1	004000132R	Feder
7	1	4191018AR	Seilrolle
8	2	3024007	Ring
9	1	61250056R	Flansch
10	2	4191017A	Feder
11	3	3918006	Scheibe
12	1	61200012R	Kerzenstecker
13	1	61252002R	Mitnehmer
14	1	61250197R	Zündspule
15	1	61250047R	Kabel
16	2	3801013R	Schraube
17	1	4196038	Buchse
18	1	3912009	Mutter
19	1	3818011A	Scheibe
20	1	61250014AR	Schwungrad
21	1	61250019R	Kragen
22	2	3801016	Schraube
23	1	61250020R	Kragen
24	1	3914003	Mutter
25	2	4191016	Klinke
26	1	61250023R	Kappe
27	1	3024015	Seegerring
28	1	61250017R	Gehäuse
29	1	3035015R	Lager
30	1	3025022	Ring
31	1	61250105R	Kettenrad
32	2	4191027ER	Stift
33	1	4191028R	Feder
34	1	4191153AR	Kupplung
35	1	61200067R	Feder
36	1	3960099R	Schraube






Illustration Tank un luffilter

Bild Nr	St.-Zahl	Teile Nr.	Beschreibung
1	1	61200019AR	Dichtung
2	1	61200198	Flansch
3	1	3801015	Schraube
4	1	61250075R	Filterhalter
5	1	61200196R	Dichtung
6	1	2318735BR	Vergaser WT-870B
7	1	61170016R	Luft filter
8	1	61250207R	Filterdeckel
9	1	61250076R	Tank
10	1	4098377	Schelle
11	1	61200092AR	Rohr
12	1	4161271	Rohr
13	1	4161211	Buchse
14	1	61070011A	Ventiltank
15	1	61200030AR	Rohr
16	1	61252040R	Tankdeckel
17	1	61070006	Dichtung
18	1	094600450R	Benzinfilter
19	1	61250035AR	Schienenfuss
20	5	3819006	Scheibe
21	5	3918005	Scheibe
22	1	3801013R	Schraube
23	2	61052009B	Schraube
24	1	61250027R	Hebel
25	1	3960087	Schraube
26	1	61250028BR	Startklappe
27	1	3916004	Scheibe
28	4	61200128R	Einsatz
29	4	3916008R	Scheibe
30	4	61200129R	Feder
31	4	3801016	Schraube
32	1	61250026R	Schutz
33	1	61250257	Rohr
34	1	61202038R	Dichtungssatz




Illustration Antrieb

Bild Nr	St.- Zahl	Teile Nr.	Beschreibung
1	1	61252027R	Av support kpl.
2	1	61252043	Gehäuse kpl
3	1	61170095	Feder
4	4	61040110R	Kragen
5	5	3914003	Mutter
6	1	61170094	Kombischieber
7	2	61250181R	Muffe
8	1	61250180R	Blech
9	1	3980011	Mutter
10	1	66030012	Scheibe
11	2	3801016	Schraube
12	1	61040155	Klemmschale kpl.
13	1	61040044	Feder
14	1	3918013	Scheibe
15	1	61042030	Knopf
16	1	61252049R	Rohr Ø28
17	1	61250058R	Flexibel welle
18	1	61040140R	Griff
19	1	61172043	Handgriff kpl.
20	1	3960067AR	Schraube
21	1	61170093	Blech
22	1	61170091	Gashebel
23	1	61170092	Hebel
24	1	61170096	Feder
25	1	61280067AR	Gas kabel
26	1	61250166R	Kabel
27	1	61170101	Handgriff
28	1	61170113	Blech
30	1	3960021	Schraube
31	1	61250169R	Fuehrungsholm
32	1	61040074AR	Schraube
33	1	4100456R	Schutz
34	1	4179089R	Flansch
35	1	3025019	Ring
36	1	3024010R	Ring
37	2	3035040R	Lager
38	1	61252045	Deckel kpl.
39	1	3025009	Ring
40	1	4138311A	Ring
41	1	61040144R	Getriebe gehause
42	1	61040071R	Stopfen
43	1	3901016	Schraube
44	1	3034218	Lager
45	1	61040106A	Stift
46	1	3034012R	Lager
47	1	3025022	Ring
48	1	3050018R	Kobelring





Illustration Antrieb

Bild Nr	St.- Zahl	Teile Nr.	Beschreibung
49	1	61040066	Distanzstück
50	1	61040145R	Deckel
51	1	61042032BR	Kegelradantrieb Ø28
52	1	61040133	Kegelradantrieb
53	1	3901008	Schraube
54	1	61250066R	Kegelradantrieb Ø28
55	1	61250054R	Bolzen
56	1	61110074R	Schultz
57	1	61110075R	Mutter

Walbro WT-870B



15 ■ KIT RIPARAZIONE
REPAIR KIT

Illustration Vergaser WT-870B

Bild Nr	St.- Zahl	Teile Nr.	Beschreibung
1	1	50010141	Schraube
2	2	095000164	Ring
3	1	095000141	Klappe
4	1	2318211	Stift
5	1	2318786	Welle
6	1	094600208	Feder
7	1	2318736	Schraube
8	2	2318687	Caps-lock
9	1	2318631	Schraube
10	1	2318191	Deckel
11	4	035000162	Schraube
12	1	003300197	Schraube
13	1	50050107	Deckel
14	1	003300201	Bissel
15	1	2318671	Reparatur-satz
16	1	074000240	Schraube
17	1	094600148	Feder
18	1	2318607	Feder











Illustration Schneidwerkzeuge

Bild Nr	St.- Zahl	Teile Nr.	Beschreibung
1	1	61112059A	Halbautomatischef kpl. Ø3
2	2	3960040R	Schraube
3	1	4174278	Streifen
4	4	3802004CR	Schraube
5	1	4174283A	Blech
6	1	4174275R	Klinge
7	1	4192048A	Komplett schutz
8	2	4199005A	Buchse
9	1	61110076	Einsatz
10	1	4199004	Feder
11	1	4199031A	Spule nyl. Ø3
12	1	4095673AR	Schneidblatt
13	1	4199035R	Deckel
14	1	61052031	Werkzeugsatz
15	1	63070003R	Keilriemen
16	1	4199041R	Spule nyl. Ø2,4
17	1	4199039AR	Halbautomatischef kpl. Ø3
18	1	4199008B	Einsatz
19	1	63019010A	Nylonkopf Quick load Ø3
20	1	4199048R	Feder
21	1	4199049	Zundanker
22	1	4199046	Deckel
23	1	63019012A	Nylonkopf Quick load Ø3